

Vue™ 1.1

Snapshot

Use on Dimmer	⊘
Outdoor Use	⊘
Sound-Activated	✓
DMX	✓
Master/Slave	✓
120/230 V switch	✓
Replaceable Fuse	✓
User-Serviceable	⊘

User Manual



CHAUVET.
Value · Innovation · Performance

5200 NW 108th Avenue, Sunrise, FL 33351 U.S.A.
(800) 762-1084 – (954) 577-4455
FAX (954) 929-5560
www.chauvetlighting.com

TABLE OF CONTENTS

1. Before You Begin	3
WHAT IS INCLUDED	3
UNPACKING INSTRUCTIONS	3
AC POWER.....	3
SAFETY INSTRUCTIONS.....	3
2. Introduction	4
FEATURES	4
<i>ADDITIONAL FEATURES</i>	4
DMX CHANNEL SUMMARY	4
PRODUCT OVERVIEW	5
3. Setup	5
FUSE REPLACEMENT.....	6
FIXTURE LINKING	6
<i>DMX Data Cable</i>	6
MASTER/SLAVE FIXTURE LINKING	6
MOUNTING	6
<i>Orientation</i>	6
<i>Rigging</i>	6
4. Operating Instructions	7
STANDALONE MODE (SOUND-ACTIVE, AUTO MODE):	7
DMX MODE.....	7
<i>DMX Channel Values</i>	7
<i>Setting the Starting Address</i>	8
DMX QUICK REFERENCE CHART	9
<i>DMX Address Quick Reference Chart</i>	9
GENERAL TROUBLESHOOTING	10
5. Appendix	11
GENERAL MAINTENANCE.....	11
RETURNS	11
CLAIMS	11
TECHNICAL SPECIFICATIONS.....	12
CONTACT US	12

1. BEFORE YOU BEGIN

What is Included

- Ø 1 x Vue™1.1
- Ø 1 x Power Cord
- Ø 1 x Warranty Card
- Ø 1 x User Manual

Unpacking Instructions

Immediately upon receiving a fixture, carefully unpack the carton, check the contents to ensure that all parts are present, and have been received in good condition. Notify the shipper immediately and retain packing material for inspection if any parts appear damaged from shipping or the carton itself shows signs of mishandling. Save the carton and all packing materials. In the event that a fixture must be returned to the factory, it is important that the fixture be returned in the original factory box and packing.

AC Power

To determine the power requirements for a particular fixture, see the label affixed to the back plate of the fixture or refer to the fixture's specifications chart. A fixture's listed current rating is its average current draw under normal conditions. All fixtures must be powered directly off a switched circuit and cannot be run off a rheostat (variable resistor) or dimmer circuit, even if the rheostat or dimmer channel is used solely for a 0% to 100% switch. Before applying power to a fixture, check that the source voltage matches the fixture's requirement. Check the fixture or device carefully to make sure that if a voltage selection switch exists that it is set to the correct line voltage you will use.



Not all fixtures have a voltage select switch. Please be sure to connect to the proper voltage.

Warning!

Verify that the voltage select switch on your unit matches the line voltage applied. Damage to your fixture may result if the line voltage applied does not match the voltage indicated on the voltage selector switch.

All fixtures must be connected to circuits with a suitable Earth Ground.

Safety Instructions



Please read these instructions carefully, which includes important information about the installation, usage and maintenance of this product.

- Please keep this User Manual for future consultation. If you sell the unit to another user, be sure that they also receive this instruction booklet.
- Always make sure that you are connecting to the proper voltage, and that the line voltage you are connecting to is not higher than that stated on the decal or rear panel of the fixture.
- This product is intended for indoor use only! To prevent risk of fire or shock, do not expose fixture to rain or moisture.
- Make sure there are no flammable materials close to the unit while operating.
- The unit must be installed in a location with adequate ventilation, at least 20 in (50 cm) from adjacent surfaces. Be sure that no ventilation slots are blocked.
- Always disconnect from power source before servicing or replacing lamp or fuse and be sure to replace with same lamp source.
- Secure fixture to fastening device using a safety chain. Never carry the fixture solely by its head. Use its carrying handles.
- Maximum ambient temperature (Ta) is 104° F (40° C). Do not operate fixture at temperatures higher than this.
- In the event of a serious operating problem, stop using the unit immediately. Never try to repair the unit by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center.
- Never connect the device to a dimmer pack.
- Make sure the power cord is never crimped or damaged.
- Never disconnect the power cord by pulling or tugging on the cord.
- Avoid direct eye exposure to the light source while it is on.

Caution!

There are no user-serviceable parts inside the unit. Do not open the housing or attempt any repairs yourself. In the unlikely event your unit may require service, please contact CHAUVET® at: 954-577-4455.

2. INTRODUCTION

Features

- 6-channel DMX LED moon flower
- Blackout/static/strobe
- Individual control of red, green and blue LEDs
- Built-in automated programs via master/slave or DMX
- Built-in sound activated programs via master/slave or DMX


ADDITIONAL FEATURES

- Linkable with Vue™ 1.1, Vue™ 2.1, and Vue™ 6.1
- Adjustable hanging bracket with slide rail

DMX Channel Summary

CHANNEL	FUNCTION
1	Control/Operating Mode
2	Red
3	Green
4	Blue
5	Strobing Speed/Stand-alone Speed
6	Dimmer

Product Overview



3. SETUP

Fuse Replacement

With a flat-head screwdriver, unscrew the fuse holder from its housing. Remove the damaged fuse from its holder and replace with exact same type fuse. Screw the fuse holder back in its place and reconnect power.



Disconnect the power cord before replacing a fuse and always replace with the same type fuse.

Fixture Linking

You will need a serial data link to run light shows of one or more fixtures using a DMX controller or to run synchronized shows on two or more fixtures set to a master/slave operating mode. The combined number of channels required by all the fixtures on a serial data link determines the number of fixtures the data link can support. Details on linking for DMX can be found in the DMX Primer, available from www.chauvetlighting.com.

Important: Fixtures on a serial data link must be daisy chained in one single line. To comply with the EIA-485 standard no more than 32 fixtures should be connected on one data link. Connecting more than 32 fixtures on one serial data link without the use of a DMX optically-isolated splitter may result in deterioration of the digital DMX signal.

Maximum recommended serial data link distance: 500 m (1640 ft)

Maximum recommended number of fixtures on a serial data link: 32

DMX Data Cable

Use a Belden® 9841 or equivalent cable which meets the specifications for EIA RS-485 applications. Standard microphone cables cannot transmit DMX data reliably over long distances. The cable will have the following characteristics:

2-conductor twisted pair plus a shield
Maximum capacitance between conductors – 30 pF/ft.
Maximum capacitance between conductor and shield – 55 pF/ft.
Maximum resistance of 20 ohms / 1000 ft.
Nominal impedance 100 – 140 ohms

Master/Slave Fixture Linking

1. Connect the (male) 3-pin connector side of the DMX cable to the output (female) 3-pin connector of the first fixture.
2. Connect the end of the cable coming from the first fixture which will have a (female) 3-pin connector to the input connector of the next fixture consisting of a (male) 3-pin connector. Then, proceed to connect from the output as stated above to the input of the following fixture and so on.

Mounting

Orientation

This fixture may be mounted in any safe position, provided there is adequate room for ventilation.

Rigging


It is important never to obstruct the fan or vents pathway. Mount the fixture using, a suitable C or O type clamp. Adjust the angle of the fixture by loosening both knobs and tilting the fixture. After finding the desired position, retighten both knobs.

When selecting installation location, take into consideration lamp replacement access and routine maintenance.

Safety cables must always be used.

Never mount in places where the fixture will be exposed to rain, high humidity, extreme temperature changes or restricted ventilation.

Hanging Clamp



Note!
Clamp is sold separately.

4. OPERATING INSTRUCTIONS

Standalone Mode (Sound-Active, Auto Mode):

This mode allows a single unit to run to the beat of the music, or the unit will auto change in Auto Mode.

- 1) Set dipswitches position, as desired:

Dipswitches	Function
1	Speed of effect 1
2	Speed of effect 2
3	Speed of effect 3
4	Speed of effect 4
5	Strobing speed 1
6	Strobing speed 2
7	Strobing speed 3
8	All On
9	Sound standalone mode
10	Auto standalone mode

Note: The Speed of effect and strobing effect DIP switches affect the auto programs. The strobing dipswitches work on their own when all other dipswitches are turned off and there is no DMX signal present. Also, when you combine the dipswitches for the speed and/or strobe, they stack together for greater speeds.

- 2) The unit will react to the low frequencies of music via the internal microphone in Sound Active mode, or the unit will auto change in Auto Mode.
- 3) Use the audio sensitivity knob on the back of the unit to make the unit more or less sensitive in Sound-Active mode. Turning the knob counterclockwise decreases the sensitivity; turning the knob clockwise increases the sensitivity.

This fixture will automatically recognize master slave operation when connected properly. The first fixture will be set as the master, and all fixtures following this will set as slave fixtures. You must follow daisy-chain configuration for this type of setup.

Note: Do not connect a DMX controller to the fixture(s) when you are trying to run them standalone, as this will put them in DMX mode automatically.

DMX Mode

This mode allows the unit to be controlled by any universal DMX controller. This fixture will automatically switch to DMX mode when you connect a DMX controller to it. Plug the DMX controller into the fixture. Using the DIP switches on the back of the fixture, set the DMX starting address.

DMX Channel Values

CHANNEL	VALUE	FUNCTION
1	000 ○ 024	Control/Operating Mode Red, Green, Blue mode
	025 ○ 049	Standalone mode 1 (automatic)
	050 ○ 074	Standalone mode 2 (automatic)
	075 ○ 099	Standalone mode 3 (automatic)
	100 ○ 124	Standalone mode 4 (automatic)
	125 ○ 149	Standalone mode 5 (automatic)
	150 ○ 174	Standalone mode 6 (automatic)
	175 ○ 199	Standalone mode 7 (automatic)
	200 ○ 224	Standalone mode 8 (automatic)
	225 ○ 249	Standalone mode 9 (automatic)
	250 ○ 255	Standalone (sound active)
2	000 ○ 255	Red 0% ○ 100%
3	000 ○ 255	Green 0% ○ 100%
4	000 ○ 255	Blue 0% ○ 100%
5	000 ○ 255	Standalone Speed (Mode 1-9) (Slow ○ Fast)
	000 ○ 009	Strobing Speed (Red Green Blue Mode) (No Strobe) (Slow ○ Fast)
	010 ○ 255	
6	000 ○ 255	Dimmer 0% ○ 100%

Setting the Starting Address

This DMX mode enables the use of a universal DMX controller device. Each fixture requires a start address from 1 to 512. A fixture requiring one or more channels for control begins to read the data on the channel indicated by the start address. For example, a fixture that uses 6 DMX channels and was addressed to start on DMX channel 100, would read data from channels: 100, 101, 102, 103, 104, and 105. Choose start addresses so that the channels used do not overlap, and note the start address selected for future reference. If you are unfamiliar with DMX, download the DMX Primer from www.chauvetlighting.com.

Set the start address using the group of DIP switches located usually on bottom of the fixture. Each DIP switch has an associated value. Adding the value of each switch in the ON position will provide the start address. Figuring out which switches to toggle ON given a specific start address can be accomplished by determining which switch values will add up to the address value, and turning these switches on. Do so by doing the following:

- 1) Determine the largest value switch that is less than the start address. Turn this switch on.
- 2) Subtract the value of the switch you just turned on from the starting address number.
- 3) Determine the largest value switch that is less than the remainder from the previous subtraction. Turn this switch on.
- 4) Subtract the value of the switch you just turned on from the remainder of the previous subtraction.
- 5) Repeat steps three and four until you have a remainder of zero.

EXAMPLE STARTING ADDRESS

<p>Address 10</p> <p>Switch # 4 = 8 Switch # 2 = 2 Total = 10</p>	<p>256 128 64 32 16 8 4 2 1</p> <p>9 8 7 6 5 4 3 2 1</p> <p>ON OFF</p>																				
<p>Address 26</p> <p>Switch # 5 = 16 Switch # 4 = 8 Switch # 2 = 2 Total = 26</p>	<p>256 128 64 32 16 8 4 2 1</p> <p>9 8 7 6 5 4 3 2 1</p> <p>ON OFF</p>																				
<p>Resolving address using simple math.</p> <p>Address 233</p>	<p>233 – (128) = 105, Turn ON DIP # 8 105 – (64) = 41, Turn ON DIP # 7 41 – (32) = 9, Turn ON DIP # 6 9 – (8) = 1, Turn ON DIP # 4 1 – (1) = 0, Turn ON DIP # 1</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>DIP SWITCH</th> <th>(DMX VALUE)</th> </tr> </thead> <tbody> <tr><td>1</td><td>1</td></tr> <tr><td>2</td><td>2</td></tr> <tr><td>3</td><td>4</td></tr> <tr><td>4</td><td>8</td></tr> <tr><td>5</td><td>16</td></tr> <tr><td>6</td><td>32</td></tr> <tr><td>7</td><td>64</td></tr> <tr><td>8</td><td>128</td></tr> <tr><td>9</td><td>256</td></tr> </tbody> </table>	DIP SWITCH	(DMX VALUE)	1	1	2	2	3	4	4	8	5	16	6	32	7	64	8	128	9	256
DIP SWITCH	(DMX VALUE)																				
1	1																				
2	2																				
3	4																				
4	8																				
5	16																				
6	32																				
7	64																				
8	128																				
9	256																				

DMX Quick Reference Chart

DMX Address Quick Reference Chart

Dip Switch Position

DMX DIP SWITCH SET 0=OFF 1=ON X=OFF or ON					Dip Switch Position															
#9	#8	#7	#6		0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	
#8	#7	#6			0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	
#7	#6				0	0	1	1	0	0	1	1	0	0	1	1	0	0	1	
#6					0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	
#1	#2	#3	#4	#5																
0	0	0	0	0		32	64	96	128	160	192	224	256	288	320	352	384	416	448	480
1	0	0	0	0	1	33	65	97	129	161	193	225	257	289	321	353	385	417	449	481
0	1	0	0	0	2	34	66	98	130	162	194	226	258	290	322	354	386	418	450	482
1	1	0	0	0	3	35	67	99	131	163	195	227	259	291	323	355	387	419	451	483
0	0	1	0	0	4	36	68	100	132	164	196	228	260	292	324	356	388	420	452	484
1	0	1	0	0	5	37	69	101	133	165	197	229	261	293	325	357	389	421	453	485
0	1	1	0	0	6	38	70	102	134	166	198	230	262	294	326	358	390	422	454	486
1	1	1	0	0	7	39	71	103	135	167	199	231	263	295	327	359	391	423	455	487
0	0	0	1	0	8	40	72	104	136	168	200	232	264	296	328	360	392	424	456	488
1	0	0	1	0	9	41	73	105	137	169	201	233	265	297	329	361	393	425	457	489
0	1	0	1	0	10	42	74	106	138	170	202	234	266	298	330	362	394	426	458	490
1	1	0	1	0	11	43	75	107	139	171	203	235	267	299	331	363	395	427	459	491
0	0	1	1	0	12	44	76	108	140	172	204	236	268	300	332	364	396	428	460	492
1	0	1	1	0	13	45	77	109	141	173	205	237	269	301	333	365	397	429	461	493
0	1	1	1	0	14	46	78	110	142	174	206	238	270	302	334	366	398	430	462	494
1	1	1	1	0	15	47	79	111	143	175	207	239	271	303	335	367	399	431	463	495
0	0	0	0	1	16	48	80	112	144	176	208	240	272	304	336	368	400	432	464	496
1	0	0	0	1	17	49	81	113	145	177	209	241	273	305	337	369	401	433	465	497
0	1	0	0	1	18	50	82	114	146	178	210	242	274	306	338	370	402	434	466	498
1	1	0	0	1	19	51	83	115	147	179	211	243	275	307	339	371	403	435	467	499
0	0	1	0	1	20	52	84	116	148	180	212	244	276	308	340	372	404	436	468	500
1	0	1	0	1	21	53	85	117	149	181	213	245	277	309	341	373	405	437	469	501
0	1	1	0	1	22	54	86	118	150	182	214	246	278	310	342	374	406	438	470	502
1	1	1	0	1	23	55	87	119	151	183	215	247	279	311	343	375	407	439	471	503
0	0	0	1	1	24	56	88	120	152	184	216	248	280	312	344	376	408	440	472	504
1	0	0	1	1	25	57	89	121	153	185	217	249	281	313	345	377	409	441	473	505
0	1	0	1	1	26	58	90	122	154	186	218	250	282	314	346	378	410	442	474	506
1	1	0	1	1	27	59	91	123	155	187	219	251	283	315	347	379	411	443	475	507
0	0	1	1	1	28	60	92	124	156	188	220	252	284	316	348	380	412	444	476	508
1	0	1	1	1	29	61	93	125	157	189	221	253	285	317	349	381	413	445	477	509
0	1	1	1	1	30	62	94	126	158	190	222	254	286	318	350	382	414	446	478	510
1	1	1	1	1	31	63	95	127	159	191	223	255	287	319	351	383	415	447	479	511

Dip Switch Position

DMX Address

General Troubleshooting

Symptom	Solution(s)	Applies to			
		Lights	Foggers & Snow	Controllers	Dimmers & Chaser
Auto shut off	Check fan thermal switch reset	ü			
Beam is very dim or not bright	Clean optical system or replace lamp Check 220/110v switch for proper setting	ü			
Breaker/Fuse keeps blowing	Check total load placed on device				ü
Chase is too slow	Check users manual for speed adjustment	ü		ü	ü
Device has no power	Check for power on Mains. Check device's fuse. (internal and/or external)	ü		ü	ü
Fixture is not responding	Check DMX Dip switch settings for correct addressing Check DMX cables Check polarity switch settings	ü			
Fixture is on but there is no movement to the audio	Make sure you have the correct audio mode on the control switches. If audio provided via ¼" jack, make sure a live audio signal exists Adjust sound sensitivity knob	ü		ü	ü
Loss of signal	Use only DMX cables Install terminator Note: Keep DMX cables separated from power cables or black lights.	ü	ü	ü	ü

If you still have a problem after trying these solutions, contact CHAUVET® Technical Support.

5. APPENDIX

General Maintenance

To maintain optimum performance and minimize wear fixtures should be cleaned frequently. Usage and environment are contributing factors in determining frequency. As a general rule, fixtures should be cleaned at least twice a month. Dust build up reduces light output performance and can cause overheating. This can lead to reduced lamp life and increased mechanical wear. Be sure to power off fixture before conducting maintenance.

Unplug fixture from power. Use a vacuum or air compressor and a soft brush to remove dust collected on external vents and internal components. Clean all glass when the fixture is cold with a mild solution of glass cleaner or Isopropyl Alcohol and a soft lint free cotton cloth or lens tissue. Apply solution to the cloth or tissue and drag dirt and grime to the outside of the lens. Gently polish optical surfaces until they are free of haze and lint.

The cleaning of internal and external optical lenses and/or mirrors must be carried out periodically to optimize light output. Cleaning frequency depends on the environment in which the fixture operates: damp, smoky or particularly dirty surrounding can cause greater accumulation of dirt on the unit's optics. Clean with soft cloth using normal glass cleaning fluid. Always dry the parts carefully.

Returns

Returned merchandise must be sent prepaid and in the original packing, call tags will not be issued. Package must be clearly labeled with a Return Merchandise Authorization Number (RMA #). Products returned without an RMA # will be refused. Call CHAUVET® and request RMA # prior to shipping the fixture. Be prepared to provide the model number, serial number and a brief description of the cause for the return. Be sure to properly pack fixture, any shipping damage resulting from inadequate packaging is the customer's responsibility. CHAUVET® reserves the right to use its own discretion to repair or replace product(s). FedEx packing or double-boxing are recommended.

Note: If you are given an RMA #, please include the following information on a piece of paper inside the box:

- 1) Your name
- 2) Your address
- 3) Your phone number
- 4) RMA #
- 5) A brief description of the symptoms

Claims

Damage incurred in shipping is the responsibility of the shipper; therefore the damage must be reported to the carrier upon receipt of merchandise. It is the customer's responsibility to notify and submit claims with the shipper in the event that a fixture is damaged due to shipping. Any other claim for items such as missing component/part, damage not related to shipping, and concealed damage, must be made within 7 days of receiving merchandise.

Technical Specifications

WEIGHT & DIMENSIONS

Length 10 in (254 mm)
Width 8.5 in (216 mm)
Height 7.5 in (190 mm)
Weight 5 lbs (2.3 kg)

POWER

Switchable, AC power 120/230 V, 50/60 Hz
Fuse F 1 A, 250 V
Power Consumption @ 120 V 19 W (0.2 A)
Inrush Current @ 120 V 0.4 A
Power Consumption @ 230 V 14 W (0.1 A)

LIGHT SOURCE

LED84 (36 Red, 24 Green, 24 Blue) 100,000 hrs

PHOTO OPTIC

Coverage Angle 34°

THERMAL

Maximum ambient temperature 104° F (40° C)

CONTROL & PROGRAMMING


Data input locking 3-pin XLR male socket
Data output locking 3-pin XLR female socket
Data pin configuration pin 1 shield, pin 2 (-), pin 3 (+)
Protocols USITT DMX512-A
DMX Channels6

ORDERING INFORMATION

Vue™ 1.1 VUE1.1

WARRANTY INFORMATION

Warranty 2-year limited warranty



Contact Us

Worldwide

General Information

CHAUVET® Lighting
5200 NW 108th Avenue
Sunrise, FL 33351
voice: 954.577.4455
fax: 954.929.5560
toll free: 800.762.1084

Technical Support

CHAUVET® Lighting
5200 NW 108th Avenue
Sunrise, FL 33351
voice: 954.577.4455 (**Press 4**)
fax: 954.929.5560 (**Attention: Service**)

World Wide Web

www.chauvetlighting.com