



# Strobe Controller

The CH-751 basic strobe controller will control between 1 and 6 mono strobes, and features a flash on demand button, speed adjustable auto button, and sound-activation mode. The CH-751 is designed to be mounted flush in a DJ booth, and includes a 33ft. linking cable.

# Lo destacado

- Controls up to 6 monostrobes
- On / Off switch
- Bump button for temporary flashes
- Sound activation and speed control
- Includes EST-MONO25FT cable (25ft)

## Especificaciones

- Peso: 1.4lbs
- Tamaño: 6in x 3in x 2.5in 152mm x 76mm x 64mm
- Power: Switchable 110v / 230v

## Lo que incluye