

Software Upload Instructions

1. Download the ZIP file onto your computer from the web page and extract the folder.
2. Transfer the content from the folder onto a USB thumb drive.
3. Hold down the menu button and power on the GigBar Move + ILS, this will put the unit into upload mode.
4. Insert the USB thumb drive into the USB port on the rear of the unit, the fixture will now update its firmware and reset automatically.
5. While the unit is resetting, remove the USB thumb drive.
6. While rebooting the display should show the new firmware version.

Notes

- The USB thumb drive capacity should not be larger than 32G
- The USB thumb drive must be formatted to FAT32